

HI-5 - The Compact Retro Hot-shoe Flash For All Camera Models

- Universal hot shoe: Compatible with all types of cameras
- 26 watt seconds: 7 different power levels to choose from
- Two flash modes: Choose between automatic and manual mode
- Long-life battery: 2,500 mAh for up to 650 flashes on a full charge
- Vertical adjustment: 4 different levels for direct and indirect flashes



Camera not included.

Technical Data

Power	26 Ws
Guide number	16
Modes	Manual / Automatic
Synchronisation modes	Normal
Power adjustment	7 steps
Flash duration (t = 0.5 s)	Normal: 1/3.000 - 1/49.000 s
Recycling time	1.6 sec. (at full power)
Burst mode: pictures per second	Up to 10 shots per sec.
Color temperature	6,000 K +/- 200 K
Battery operation Charging time	Lithium battery: 3.7 V, 2,500 mAh, 9.25 Wh Input: 5.0 V, 2.0 A max. approx. 75 min
Flashes in battery operation	> 650 (at full power)
Additional features	USB-C for charging and firmware updates
Compatible camera brands	Canon, Nikon, Fuji, Panasonic, Olympus, Sony
Dimensions (L x W x H) Weight	9 x 5.5 x 7.5 cm 215 g

What's in the Box and Packaging Details

What's in the box	HI-5, USB-C cable, SYNC cable, diffuser, carrying case, manual
Packaging dimensions (L x W x H) Weight	11.7 x 8.3 x 15.3 cm 425 g

Specifications are subject to change without notice.