



Canon
1DX
EOS 1DX MARK II
EOS 1DS MARK III
EOS 1DX MARK III
EOS 1D MARK 4
EOS 5D MARK 4
EOS 5D MARK II
EOS 5D MARK III
EOS 5DS
EOS 5DSR
EOS 5D
EOS 7D MARK II
EOS 7D
EOS 6D MARK 2
EOS 6D
EOS 90D
EOS 80D
EOS 70D
EOS 60D
EOS 80D
EOS 70D
EOS 60D
EOS 600D
EOS 100D
EOS 550D
EOS-R5
EOS-R6
EOS-R/RP

Nikon
D5
D4S
D850
D810
D800
D700
D610
D600
D500
D60
D90
D7500
D7200
D7100
D7000
D3200
Z7II
Z6II
Z7
Z50
Z6

Sony
α99II
α1
α9 II
α9
α7R IV
α7C
α7S III
α7 IV
α7 R3/S3
α7 III
α7
α7R
α6500
α6000

Fuji
GFX-50s
GFX-50r
GFX-100S
GFX-100
XT-4
XT3
XT2
X-S10
XT20

Panasonic
Lumix DC-GH5
Lumix DC-GH5S
Lumix DC-S1R
Lumix DC-S1

Olympus
E-M5 MARK II
E-M1 MARK II
OM-D E-M1X
OM-D E-M1 MARK III